







CD1000-2

Coupling device





Intended use

The CD1000-2 can be employed with an NGR monitor in HRG installations with a system voltage $U_{\rm LL}$ up to 1000 V ($U_{\rm NGR} \le 600$ V). It can be used at maximally 5000 m AMSL.

Functional description

The duty time is unlimited. To provide the necessary cooling at a voltage of $U_{\rm LL}>690$ V ($U_{\rm NGR}>400$ V), the CD1000-2 should be mounted on a grounded metal plate of at least 300 x 300 mm.

Safety instructions

Part of the device documentation in addition to this manual are the enclosed "Safety instructions for Bender products".

All work activities necessary for the installation, connection and commissioning are to be carried out by electrically skilled persons only! It is essential to follow the current safety instructions.



Danger of an electric shock!


The coupling device is operated with voltages up to 600 V. Wrong connection can lead to death, serious physical injury or substantial damage to property. Before working on the coupling device, make sure that the operating area is de-energized!

Expected surface temperatures during an HRG ground fault

	U _{LL}	U _{NGR}	Surface temperature at ambient temperature		Dututimo
			25 °C	70 °C	Duty time
without heat sink	690 V	400 V	45 °C	90 °C	∞
with heat sink 300 x 300 mm	1000 V	577 (600) V	30 ℃	75 ℃	∞
	Overload capacity ≤ 1200 V	690 V	70℃	115 ℃	< 30 min

Dimension diagram

All dimensions in mm (in)



CD1000-2 dimension diagram from the top (left) and the side (right)


Installation and connection



DANGER of an electric shock!


Inappropriate installation and connection can result in death, serious physical injury or substantial damage to property.


The device is suitable for screw mounting. For $U_{\rm LL}$ > 690 V, a cooling surface of 300 x 300 mm (11.81 in²) must be provided.





Wiring diagram





Wiring diagram (left), CD1000-2 internal wiring diagram (right)

So that the connection between NGR and star point is also monitored, the "N" terminal of the CD1000-2 should be connected directly to the star point of the transformer.

A direct connection between the "N" connections of the CD1000-2 and the NGR is not recommended, as in this case a line interruption between the star point and the NGR connection "N" would not be monitored.

Notes on the wiring diagram:

Terminal	II	Connecting cable	
	Use	Metrisch	Imperial
N	Connection to the star point of the HRG system	1.5 mm ² AWG16	
\mathbf{R}_{s}	Connection to $R_{\scriptscriptstyle S}$ of the NGRM		
E	Connection to protective earth conductor (internally connected to PE)		
PE	Connection to the protective conductor (internally connected to E, cable lug M4	≥ 1.5 mm ²	≥ AWG16

Commissioning

After connecting the CD1000-2 to the NGR monitor, perform a field calibration.

To obtain the best possible results in a field calibration, the NGR monitor should be in operation for at least one hour in the operational environment.



Technical data

Insulation coordination DIN EN 50178:1997 Definition
Measuring circuit (IC1)N
Output circuit (IC2)Rs
Protective circuit (IC3) E, PE
Rated voltage600 V
Overvoltage categoryIII
Pollution degree2
Rated insulation voltage
No galvanic separation between the circuits!
IC1 / (IC2 – IC3)600 V
IC2 / IC350 V
Voltage range
<i>U</i> _n
<i>I</i> _n 30 mA
Overload capacity
Resistance
20 kΩ±0.5 %
Temperature coefficient
Environment
Ambient temperature40+70 °C
Ambient temperature for UL40+60 °C
Humidity≤ 98 %
Classification of climatic conditions acc. to IEC 60721
(with respect to temperature and rel. humidity)
Stationary use (IEC 60721-3-3)3K22
Transport (IEC 60721-3-2)
Long-term storage (IEC 60721-3-1)

Classification of mechanical conditions acc. to IEC 60721
Stationary use
Transport
Long-term storage1M12
Connection
Tightening torque
Conductor sizesAWG 24-12
Stripping length
Conductor, rigid
Conductor, flexible
Multiple conductor, flexible with ferrule
without plastic sleeve
with plastic sleeve
Multiple conductor, flexible with TWIN ferrule
with plastic sleeve
Other
Operating modecontinuous operation
Mounting any position
Screw type for mounting screws
Tightening torque for mounting screws ()2.5 Nm (22.1 lb-in)
Operating altitudeup to 5000 m AMSL
Degree of protection, internal components (DIN EN 60529)IP30
Flammability classUL 94V-0
Weight< 700 g

Ordering details

Name	U_{LL}	U_{NGR}	Ordering no.
CD1000-2	up to 1000 V	600 V	B98039053



All rights reserved. Nachdruck und Vervielfältigung nur mit Genehmigung des Herausgebers.

Bender GmbH & Co. KG

Postfach 1161 • 35301 Grünberg • Deutschland Londorfer Str. 65 • 35305 Grünberg • Deutschland Tel.: +49 6401 807-0 • Fax: +49 6401 807-259 E-mail: info@bender.de • www.bender.de









All rights reserved. Reprinting and duplicating only with permission of the publisher.

Bender GmbH & Co. KG

PO Box 1161 • 35301 Grünberg • Germany Londorfer Str. 65 • 35305 Grünberg • Germany Tel.: +49 6401 807-0 • Fax: +49 6401 807-259 E-mail: info@bender.de • www.bender.de