

CE CA CONSTRUCTIONAL voltage relay

Intended use

Quickstart

The multifunctional voltage monitoring relay **VMD461** monitors frequencies, undervoltages and overvoltages in DC, AC and 3(N)AC systems. The phase voltages and/or line-to-line voltages are measured as r.m.s. value and are continuously shown on the device display. The measured value required to trigger the alarm relay is stored. The VMD461 features additional measuring functions for:

- ROCOF df/dt
- Vector shift monitoring
- Unbalance monitoring
- Phase sequence monitoring

The corresponding ANSI codes for all available measuring functions are provided.

Configurable delay times allow considering special installation-specific properties (e.g. device-specific start-up procedures). The VMD461 requires an external supply voltage.

The optional use of a CD440 coupling device extends the voltage range that can be monitored to DC/ 3AC 1200 V or 1AC/3NAC 690 V. Any other use than that described in this manual is regarded as improper. The guickstart does not replace the manual of the device. Download: www.bender.de/manuals

Safety instruction

DANGER

Danger of electrocution due to electric shock!

Touching live parts of the system carries the risk of:

- An electric shock
- Damage to the electrical installation
- Destruction of the device

Before installing and connecting the device, make sure that the installation has been de-energised. Observe the rules for working on electrical installations.

Dimension diagrams VMD461 (left) und CD440 (right) in mm











Mounting on DIN rail and screw mounting



Wiring

Depending on the application, connect the device according to the following wiring diagrams..



The VMD461 can be operated without a CD440 in appropriate power supply systems (230/400 V).



Risk of unwanted device failure!

Do not supply device from the monitored system. Pay attention to maximum supply voltage.

Legend wiring diagrams

Element	Funktion			
A1, A2	Supply voltage U _s (see ordering details)			
L1, L2/DC+, L3, N/DC-	Power supply connection			
11, 12, 14	Connection to alarm relay K1			
21, 22, 24	Connection to alarm relay K2			
DG1/2,	Contact monitoring			
D1, D2 DG1/2: GND				
-	D1: Feedback signal contact to alarm relay K1			
	D2: Feedback signal contact to alarm relay K2			
	(feedback signal contacts optionally NC/NO/off)*			
RTG, RT1	RTG: GND			
	RT1: Remote-trip input (<i>optionally NC/NO/off</i>)*			
А, В	Connection to communication interface BMS bus			
R _{on/off}	Activate or deactivate the terminating resistor of the BMS bus (120 Ω)			

* Explanation: NC (closed in non-operating state)

NO (open in non-operating state) **_____ off** (switched off)



Unearthed system





Earthed system





DC



Details regarding the digital inputs (D1, D2, RT1)





Initial commissioning

When commissioning the device for the first time you have to:

- Select a language (English, German, French) (menu 4.2).
- Set date and time (menu 4.3).

You can only change settings in the menus after the settings listed above have been carried out



The **contrast of the LC display** can be adjusted to any ambient brightness. Select the contrast ratio from an infinite loop display. Simultaneously press and hold down the buttons "INFO" and "MENU" until the display text is clearly readable. After reaching a black display, the contrast setting process starts again with a white display.

User interface



Legend

	Power On LED, green;					
Element	nt lights when the voltage supply is available and the device is in operation;					
	flashes when the device is being started or when an internal device error has occurred					
ON	Alarm LEDs, yellow: installation switched off					
	Only ALARM 1 lights: alarm relay K1 has tripped					
	Only ALARM 2 lights: alarm relay K2 has tripped					
	ALARM 1 and ALARM 2 light: response value violation of voltage or frequency, df/dt, vec-					
	tor shift detection, unbalance, phase sequence, remote trip					
	ALARM 1 and ALARM2 flash: internal device error or error in contact monitoring					
ALARM1 ALARM2	Backlit LC display					
INFO	Standard display: Toggle between standard display and device information					
FSC	Menu display: Exit the parameter setting menu without saving; switch to the next higher					
150	menu level					
TEST	Standard display: Use the TEST button (< 1.5 s) to start a manual self test which triggers					
	both alarm relays (trigger test to check the switches/disconnectors). In addition, the					
•	switch-off times are documented, .					
	Menu display: arrow-up button for parameter change and scrolling					
RESET	Standard display: (> 1.5 s) Acknowledge fault messages from contact monitoring					
▼	Menu display: arrow-down button for parameter change/scrolling					



 MENU
 Standard display: Toggle between standard, menu and alarm display

 Menu display:
 Jbutton

 Jump to setting parameter; save the changed parameters

Toggling between the individual displays



You can toggle between the different displays by using the four device buttons. Depending on the type of display (standard display, alarm display, menu display, info display), the meaning of the buttons is different. The picture below illustrates which button is to be pressed for accessing the individual display. First, you have to distinguish between an alarm condition and no alarm condition.

LEDs

The state of the VMD461 can be determined by means of the LEDs. The following table provides an overview of the possibilities.

LED	Meaning	LED	Meaning	Action
 2 ALARM 1 ON 	Normal operation mode: device in operation, all the measured values are within the specified limits	 2 ALARM 1 ON 	Alarm, limit value of K1 violated	
2 ALARM 1 ON	Alarm, limit value of K1 and K2 violated		Error contact monitor- ing or internal error	Check switches/dis- connectors * ; in case of int. errors: contact service
2 ALARM 1 ON	Alarm, limit value of K2 violated	○ 2 ALARM ○ 1 ON	Device starts (> 10 s): internal device error	Wait (< 10 s) Contact service



Menu

1. Alarm/meas. values	$\begin{array}{l} U_{(1-N)}, U_{(2-N)}, U_{(3-N)}, U_{(1-2)}, U_{(2-3)}, U_{(3-1)}, Unbalance, Phase sequence, \\ Frequency, df/dt (81R), Vect.sh.(78), Status, t_{on1}, t_{on2}, t_{off total} \end{array}$				
2. History	History				
	Thotory				
3. Settings	1. General	Coupling, System type, $U_{(L\text{-}N)},t_{\text{start-up}},\text{Remote trip}$			
	2. Voltage (59/27)	$\begin{array}{l} U>>> (59.S3), t_{off} \\ U>> (59.S2), t_{off} \\ U> (59.S1), t_{off} \\ U (on)max, U (on)min \\ U< (27.S1), t_{off} \\ U<< (27.S2), t_{off} \\ U<< (27.S3), t_{off} \end{array}$			
	3. Frequenc <u>y(81)</u>	f>>> (81>.S3), t _{off} f>> (81>.S2), t _{off} f> (81>.S1), t _{off} f _{(on)max} . f _{(on)min} f< (81<.S1), t _{off} f<< (81<.S2), t _{off} f<<< (81<.S3), t _{off}			
	4. df/dt (81R)	Function, Resp.value, Hysteresis, Meas.window, toff, ton			
	5. Vect.sh. (78)	Function, Resp.value, t _{start-up} , t _{on}			
	6. Unbalance (47)	Function, Resp.value, Hysteresis, t _{off}			
	7. Phase sequence(47)	Function, Phase sequence			
	8. Rela <u>ys</u>	Relay mode, t _{on} , Fault memory, Start alarm, Device error, TEST, U>>> (59.S3), U>> (59.S2), U> (59.S1), U< (27.S1), U< (27.S2, U<< (27.S3), f>>> (81>.S3),f>> (81>.S2), f> (81>.S1), f< (81<.S1), f<< (81<.S2), f<< (81<.S3), df/dt (81R), Vect.sh. (78), Unbalance, Phase sequence, Remote trip			
	9. Dig. input	Mode, t _{start-up}			
4 <mark>. System</mark>	Delete history, Language, Clock, Password, Interface, Alarm addresses, TEST, RESET, Test communication, External devices, Service, Factory settings				
5 <u>. Info</u>	Device type, Current date and time, BMS bus address, Software version measurement technology, Software date measurement technology, Software version display, Software date display, Manufacturer of the device, Address of the manufacturer, Internet address of the manufacturer				





BENDER Group

© Bender GmbH & Co. KG All rights reserved. Reprinting only with permission of the publisher. Subject to change!

Bender GmbH & Co. KG

P.O. Box 1161 • 35301 Grünberg • Germany Londorfer Strasse 65 • 35305 Grünberg • Germany Tel.: +49 6401 807-0 • Fax: +49 6401 807-259 E-Mail: info@bender.de • www.bender.de